



CLEAN & PREP.

The Tele-Wash quickly cleans many outdoor surfaces including wood, composite, brick, stone, tile and concrete. Telewash is the perfect wood deck cleaning tool. It won't damage wood the way pressure washers can and its stiff bristles gently remove stubborn dirt while the water washes it away. Use Telewash with a deck cleaner to help bring back woods' natural beauty and prep it for staining.

★★★★★ CUSTOMER REVIEW

"Used this to clean my composite deck...This worked perfectly. The bristles are quite firm and coarse and I was hesitant to use on our deck, but it worked out well because that meant I didn't need to use as much pressure at all. Good buy and well worth it. Hope to last several seasons."

— ladybach

WOODMATES® TELE-WASH®

All weights and specifications are approximate.



WOODMATES® TELE-WASH®

Model 8689

Pack Qty: 6
Carton: 2.486 cu. ft.
Shipping Wt: 12.72 lbs.
UPC #: 039932086899

- Handle easily adjusts 3'-5' (.9 m-1.5 m)
- Stiff brush cleans under rails and gets into corners
- 100% polypropylene filaments for long life
- Attaches to a standard garden hose
- On/off valve adjusts water flow
- Non-slip rubber hand grip
- Anodized aluminum resists rust
- Cleans wood, stone, concrete, brick, tile, composites and more
- Assembled in USA with US and imported parts



Model 8689B

WOODMATES® TELE-WASH® 12-COUNT DISPLAY

Pack Qty: 1
Carton: 10.37 cu. ft.
Shipping Wt: 29.35 lbs.
UPC #: 039932086899